




tailwalk

SEIRENS 3M  
100HG-DH/R




KEY NO	Parts Name	KEY NO	Parts Name	KEY NO	Parts Name
No.1	Palm Side Cover	No.33	Washer	No.65	Gear
No.2	Control Dial	No.34	Nut	No.66	Ratchet
No.3	Leaf Spring	No.35	Screw	No.67	Washer
No.4	O-Ring	No.36	Front Support	No.68	Drive Gear
No.5	Slide Cam-A	No.37	Line Stopper	No.69	Washer
No.6	Tap Screw	No.38	Line Memory Knob	No.70	Washer
No.7	Slide Cam	No.39	Click Spring	No.71	Washer
No.8	Coil Spring	No.40	Thumb Bar	No.72	Bush(Sleeve)
No.9	Spool Cover	No.41	Tap Screw	No.73	Ball Bearing
No.10	Tap Screw	No.42	Tap Screw	No.74	Washer
No.11	Magnet Holder ASSY	No.43	Spring	No.75	Washer
No.12	Washer	No.44	Kick Lever	No.76	Leaf Spring ASSY
No.13	Ball Bearing	No.45	Spring	No.77	Spring Washer
No.14	Ring	No.46	Clutch Cam	No.78	Star Drag
No.15	①Spool ASSY (1 BB)	No.47	Clutch	No.79	Washer
No.16	Ball Bearing	No.48	Coil Spring	No.80	②Handle ASSY
No.17	Tap Screw	No.49	Pinion	No.81	Handle Arm ASSY
No.18	Plate	No.50	O/Way Clutch ASSY	No.82	Washer
No.19	Lever	No.51	Gear Side Cover	No.83	Bush
No.20	Pin	No.52	Tap Screw	No.84	Handle Knob ASSY
No.21	Coil Spring	No.53	Tap Screw	No.85	Bush
No.22	Frame	No.54	O-Ring	No.86	Screw
No.23	Retainer	No.55	Bearing	No.87	Handle Knob Cap
No.24	Bush	No.56	Ring	No.88	Nut
No.25	Level Wind ASSY	No.57	Washer	No.89	Handle Nut Cap
No.26	Pipe	No.58	Washer	No.90	Screw
No.27	Washer	No.59	Mechanical Knob	No.91	Washer
No.28	Worm Shaft	No.60	Ball Bearing	No.92	Collar
No.29	Worm Pinion	No.61	Retainer	No.93	③Palm Side Cover Unit
No.30	Retainer	No.62	Bearing Plate	No.94	④Mechanical Knob ASSY
No.31	Pillar	No.63	Gear Metal		
No.32	Level Wind Pin	No.64	Screw		



tailwalk

SEIRENIS BM  
100HG-DH/L



KEY NO	Parts Name	KEY NO	Parts Name	KEY NO	Parts Name
No.1	Palm Side Cover	No.33	Washer	No.65	Gear
No.2	Control Dial	No.34	Nut	No.66	Ratchet
No.3	Leaf Spring	No.35	Screw	No.67	Washer
No.4	O-Ring	No.36	Front Support	No.68	Drive Gear
No.5	Slide Cam-A	No.37	Line Stopper	No.69	Washer
No.6	Tap Screw	No.38	Line Memory Knob	No.70	Washer
No.7	Slide Cam	No.39	Click Spring	No.71	Washer
No.8	Coil Spring	No.40	Thumb Bar	No.72	Bush(Sleeve)
No.9	Spool Cover	No.41	Tap Screw	No.73	Ball Bearing
No.10	Tap Screw	No.42	Tap Screw	No.74	Washer
No.11	Magnet Holder ASSY	No.43	Spring	No.75	Washer
No.12	Washer	No.44	Kick Lever	No.76	Leaf Spring ASSY
No.13	Ball Bearing	No.45	Spring	No.77	Spring Washer
No.14	Ring	No.46	Clutch Cam	No.78	Star Drag
No.15	①Spool ASSY (1 BB)	No.47	Clutch	No.79	Washer
No.16	Ball Bearing	No.48	Coil Spring	No.80	②Handle ASSY
No.17	Tap Screw	No.49	Pinion	No.81	Handle Arm ASSY
No.18	Plate	No.50	O/Way Clutch ASSY	No.82	Washer
No.19	Lever	No.51	Gear Side Cover	No.83	Bush
No.20	Pin	No.52	Tap Screw	No.84	Handle Knob ASSY
No.21	Coil Spring	No.53	Tap Screw	No.85	Bush
No.22	Frame	No.54	O-Ring	No.86	Screw
No.23	Retainer	No.55	Bearing	No.87	Handle Knob Cap
No.24	Bush	No.56	Ring	No.88	Nut
No.25	Level Wind ASSY	No.57	Washer	No.89	Handle Nut Cap
No.26	Pipe	No.58	Washer	No.90	Screw
No.27	Washer	No.59	Mechanical Knob	No.91	Washer
No.28	Worm Shaft	No.60	Ball Bearing	No.92	Collar
No.29	Worm Pinion	No.61	Retainer	No.93	③Palm Side Cover Unit
No.30	Retainer	No.62	Bearing Plate	No.94	④Mechanical Knob ASSY
No.31	Pillar	No.63	Gear Metal		
No.32	Level Wind Pin	No.64	Screw		